



# 121-3341 Reference Sheet

## Start Up

This room is built on a **Standard Digital platform** and utilizes a touch panel for setting the inputs and the volume of the AV system.

To start the system, follow the on-screen prompts and wait a few seconds for everything to synch up.

## Controls



Across the top you will find the different inputs based on the device you want to display on the projector.

- **PC** is the input to select for using the room computer.
- **Laptop** is the input selection for the cables found in the tablet cubby for connecting your personal or work laptop to the system.
- **Wireless Presentation** is for the Solstice device (*see back for details*).

To the left are controls for the display.

To the right are controls for the rooms audio system.

The shut down button on the bottom right will automatically mute any audio devices in the room and turn off the display.

**Need some extra help?**

Call (909) 869-4040 | [www.cpp.edu/classroomhelp](http://www.cpp.edu/classroomhelp)

**CalPolyPomona**



# 121-3341 Reference Sheet

## Wireless Presentation

This feature is designed to allow multiple participants to share presentations from their personal devices (phones or laptops).


The Solstice Pod allows for up to **4** users to connect to a single display simultaneously.

- You'll first want to make sure your device is connected to **Eduroam** ([www.cpp.edu/wifi](http://www.cpp.edu/wifi)).
- Next, download Solstice from the **Mersive Download Center** for your device ([www.mersive.com/download](http://www.mersive.com/download)).



Once your device is set up make sure your projector is switched to the **Wireless Presentation** option on your room's controller.

Then, open the app on your device and search for your classroom in the search bar across the top using your **building and room number**.



**98-b1-267**



Enter the screen key on the room display

Connect

Cancel

Once you've selected your room, the app will prompt you to type in a **four-digit code** that is displayed on your projector.

After a few seconds your device will now show up on your projector and you can begin presenting your projects to the class.

For more information on the Wireless Presentation feature, please visit the Classroom Help site! ([www.cpp.edu/classroomhelp](http://www.cpp.edu/classroomhelp))

**Need some extra help?**

Call (909) 869-4040 | [www.cpp.edu/classroomhelp](http://www.cpp.edu/classroomhelp)

**CalPolyPomona**