

**SANYO****Pro Xtrax Multiverse Projector****INSTRUCTIONS FOR PROJECTOR USE**

1. LOCATE THE BLACK WALL PLATE LABELED **“CONTROL CENTER”**. PRESS THE **PC BUTTON**. THIS WILL TURN ON THE PROJECTOR.
2. USE THE SWITCH ON THE WALL TO LOWER THE PROJECTION SCREEN.
3. USE THE VGA WITH AUDIO CABLE IN THE TABLE TOP COMPARTMENT AND PLUG IT IN TO YOUR LAPTOP.
4. IF YOU HAVE AUDIO, PLUG THE AUDIO PORTION OF THE CABLE INTO THE HEADPHONE JACK ON YOUR LAPTOP. (THERE IS VOLUME CONTROL ON THE “CONTROL CENTER” WALL PLATE.)
5. YOU MAY HAVE TO TOGGLE THE VIDEO OUTPUT FROM YOUR LAPTOP BY SIMULTANEOUSLY DEPRESSING THE “FUNCTION KEY” AND ONE OF THE “F” KEYS LABELED WITH A “Monitor Icon”.

**\*\*\*\*\*WHEN YOU ARE DONE\*\*\*\*\***

1. TURN THE PROJECTOR OFF BY PRESSING AND HOLDING THE **PC BUTTON** FOR **5 SECONDS** ON THE “CONTROL CENTER” PLATE.
2. USE THE WALL SWITCH TO RAISE THE SCREEN.

